

#091503179 LEAD - EMPLOYEE AIR SAMPLE

65 McCoppin Street
San Francisco, CA 94103
415.552.5511; Fax 415.543.6510
www.cpmenvironmental.com

CA License #838116; DOSH #1009

Date: 2-5-15
Project: Duck Linker
CPM Job No: 4015-006
Address: 321 GOLF club Rd
City, State, Zip: Redwood San Hill CA
Sample(s) by: Ruben Padilla

Day (Circle One): M - T - W - TH - F - SA - SU
Shift (Circle One): DAY NIGHT
Weather (Circle One): CLEAR RAIN HOT COLD
Filter Dia. (Circle One): 25mm 37mm Other: ___
Pore Size (Circle One): .45pm .8pm Other: ___
Location: ZONA 1

PPM TEM PAS	TURNAROUND TIME	1428
	6-Hour	<input checked="" type="checkbox"/>
	3 Days	<input type="checkbox"/>
Other:		___
<input checked="" type="checkbox"/> FAX RESULTS TO: 415-543-6510		
<input checked="" type="checkbox"/> E-MAIL: results@cpmenvironmental.com		
<input type="checkbox"/> U.S. MAIL: Use Above Address		

SAMPLE No.	PUMP No.	RTMTR No.	NAME OF EMPLOYEE		EE SS#			WORK TASK	WORK AREA	
13	12	12	JOSE A VASQUEZ		000 007632					
TIMES	AM / PM START +	AM / PM STOP =	TOTAL MINUTES	FLOW RATES		START +	STOP/2=	AVE.	SAMPLE VOLUME	SPECIAL INSTRUCTIONS:
	8:00	9:00	60	MULTIPLY TOTAL MINUTES BY AVE. FOR SAMPLE VOLUME		2.63	2.67	2.63	157.8	Remove Drywall
14	12	12	JOSE A VASQUEZ		000 007632					
TIMES	AM / PM START +	AM / PM STOP =	TOTAL MINUTES	FLOW RATES		START +	STOP/2=	AVE.	SAMPLE VOLUME	SPECIAL INSTRUCTIONS:
	9:00	11:00	120	MULTIPLY TOTAL MINUTES BY AVE. FOR SAMPLE VOLUME		2.63	2.63	2.63	315.6	Remove Drywall
15	12	12	JOSE A VASQUEZ		000 007632					
TIMES	AM / PM START +	AM / PM STOP =	TOTAL MINUTES	FLOW RATES		START +	STOP/2=	AVE.	SAMPLE VOLUME	SPECIAL INSTRUCTIONS:
	12:00	7:00	18:00	MULTIPLY TOTAL MINUTES BY AVE. FOR SAMPLE VOLUME		2.63	2.63	2.63	473.4	Remove Drywall
16	***	**	Blank Blank		Blank			Blank	Blank	
TIMES	AM / PM START +	AM / PM STOP =	TOTAL MINUTES	FLOW RATES		START +	STOP/2=	AVE.	SAMPLE VOLUME	SPECIAL INSTRUCTIONS:
				MULTIPLY TOTAL MINUTES BY AVE. FOR SAMPLE VOLUME						BLANK

INSTRUCTIONS TO ANALYST:
COMBINE THE FOLLOWING SAMPLES
TO CALCULATE THE (TWA)

)PLUS"+") PLUS"+") PLUS"+") = (TWA)
OTHER: Ruben Padilla 10909 mail-com

RELINQUISHED BY: Ruben Padilla PHONE NO#: (907) 202 28 DATE: 2-5-15
RECEIVED BY: EA SIGNATURE: _____ DATE: 3/5/15 4:15pm (w.1)
RECEIVED BY: _____ SIGNATURE: _____ DATE: _____